















8.1 place the skylight frame on additional battens.	8.2 cut through a rectangular hole the size as the frame	8.3 rectangular hole for the window	8.4 apply the bottom covering stripe from the same membrane	8.5 fix the stripe with the staples to the window frame
				
8.6 fix the stripe to a counter batten and make a cut at corner	8.7 Y-shaped cut above a counter batten, membr. fixed with staples	8.8 place regular batten over the bottom covering membrane stripe	8.9 apply the side covering stripe from the same membrane	8.10 fix the membrane side covering strip over a frame corner
				
8.11 fix the stripe to a frame and make a cut at the top corner	8.12 Y-shaped cut above a counter batten	8.13 6 fix the side stripe to a counter batten with staples	8.14 8 place regular batten above the window frame	8.15 apply upper covering stripe from the same membrane
				
8.16 Y-shaped cut above a counter batten	8.17 fix the upper stripe to a counter batten with staples	8.18 add drainage ditch above the window frame	8.19 add upper counter batten so the drainage is functional	8.20 skylight with membrane border



Breathable membrane – SKYLIGHT

BREATHABLE MEMBRANE – INSTALLATION – SKILIGHT

- The breathable waterproof underlay JUTADACH must be fixed to the skylight’s frame from its side and up to the upper frame’s crimping groove.
- Above the skylight must be installed the drainage ditch (Obr. 8.18-8.19)
- The skylight is placed on additional battens, rectangular hole is the same size as the skylight’s frame. (Obr. 8.1-8.3)
- The skylight membrane border is always made of breathable waterproof membrane (JUTADACH). At first the bottom covering stripe is made. A regular batten is placed over the bottom covering membrane stripe . (Obr. 8.4-8.8).
- Over the bottom covering stripe is placed the side covering stripe.
- This is done on both sides of the skylight frame (Obr. 8.9-8.13)
- Than a regular batten is placed above the window over the side covering stripes. (Obr. 8.14)
- Finally upper covering stripe from the same membrane is placed and fixed to the skylight frame. (Obr. 8.15-8.16).



SKYLIGHT – detail of bottom corner



SKYLIGHT – side detail



SKYLIGHT – detail of upper corner